

Quick Start Guide

1

PLUG IN SAFESTICK

- Wait for up to 30 seconds.
- No need to restart your computer.
- Drive letters vary with computer.

2


SETUP/UNLOCK*

Device autostarts or **Double-click & Run**



3

WORK



Manage Files



SafeStick locks when it is unplugged, powered down, timed out, locked from the menu or when you log out.

For more information, instructions and FAQs,
visit datalocker.com/support