



Please make sure you remember your PIN (password), without it there is no way to access the data on the drive.

If you are having difficulty using your datAshur PRO² please contact our support team by email - support@istorage-uk.com or by phone on +44 (0) 20 8991 6260.

Copyright © iStorage, Inc 2019. All rights reserved.

Windows is a registered trademark of Microsoft Corporation.

All other trademarks and copyrights referred to are the property of their respective owners.

Distribution of modified versions of this document is prohibited without the explicit permission of the copyright holder.

Distribution of the work or derivative work in any standard (paper) book form for commercial purposes is prohibited unless prior permission is obtained from the copyright holder.

DOCUMENTATION IS PROVIDED AS IS AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID

iStorage datAshur PRO[®] User Manual v2.3



All trademarks and brand names are the property of their respective owners

Trade Agreements Act (TAA) Compliant



Table of Contents

Introduction	4
Box contents	4
1. LED indicators and their actions	5
2. Battery and LED States	5
3. First Time Use.....	6
4. Unlocking datAshur PRO ² with the Admin PIN	7
5. To Enter Admin Mode	8
6. To Exit Admin Mode	8
7. Changing the Admin PIN	9
8. Setting a User PIN Policy	10
9. How to delete the User PIN Policy	11
10. How to check the User PIN Policy	12
11. Adding a New User PIN in Admin Mode	13
12. Changing the User PIN in Admin Mode	14
13. Deleting the User PIN in Admin Mode	14
14. How to Unlock datAshur PRO ² with User PIN	15
15. Changing the User PIN in User Mode	15
16. Creating a One-Time User Recovery PIN	16
17. Deleting the One-Time User Recovery PIN	16
18. Activating Recovery Mode and Creating New User PIN	17
19. Set User Read-Only in Admin Mode	18
20. Enable User Read/Write in Admin Mode	18
21. Set Global Read-Only in Admin Mode	19
22. Enable Global Read/Write in Admin Mode	19
23. How to configure a Self-Destruct PIN	20
24. How to delete the Self-Destruct PIN	21
25. How to Unlock with the Self-Destruct PIN	21
26. How to Configure an Admin PIN after a Brute Force attack or Reset	22
27. Setting the Unattended Auto-Lock Clock	22
28. Turn off the Unattended Auto-Lock Clock	23
29. How to check the Unattended Auto-Lock Clock.....	24
30. Set Read-Only in User Mode	24
31. Enable Read/Write in User Mode	25
32. Brute Force Hack Defence Mechanism	25
33. How to set the User PIN Brute Force Limitation	26
34. How to check the User PIN Brute Force Limitation	27
35. How to perform a complete reset	28
36. How to configure datAshur PRO ² as Bootable	28
37. How to disable the datAshur PRO ² Bootable feature	29
38. How to check the Bootable setting	29
39. Formatting the datAshur PRO ² for Windows	30
40. datAshur PRO ² Setup for Mac OS	32
41. datAshur PRO ² Setup for Linux (Ubuntu 18.04 LTS)	34
42. Hibernating, Suspending or Logging off from the Operating System	37
43. How to check Firmware in Admin Mode	37
44. How to check Firmware in User Mode	38
45. Technical Support	39
46. Warranty and RMA information	39

Introduction



Note: The datAshur PRO² rechargeable battery is not fully charged, we recommend the battery be charged prior to first use. Please plug in the datAshur PRO² to a powered USB port for 30-60 minutes to fully charge the battery.

Thank you for purchasing the iStorage datAshur® PRO², an ultra-secure and easy to use, hardware encrypted USB 3.2 Gen 1 PIN authenticated flash drive with capacities up to 512GB and rising.

The datAshur PRO² incorporates a rechargeable battery allowing the user to enter a 7-15 digit PIN (Personal Identification Number) onto the on-board keypad to unlock the drive before connecting to a USB port. To lock the drive and encrypt all data, simply eject the datAshur PRO² from the host computer and the entire contents of the drive will be encrypted (full disk encryption) using military grade AES-XTS 256-bit hardware encryption. If the drive is lost or stolen and an incorrect PIN is entered 10 consecutive times (default setting), the datAshur PRO² defence mechanism will be triggered to protect against unauthorised access.

The datAshur PRO² can be configured with both User and Admin PINs and can also be programmed to include a 'User Recovery PIN' making it perfect for corporate and government deployment. As the datAshur PRO² is unlocked via the on-board keypad and not a host computer, it is not vulnerable to software/hardware based key-loggers or brute force attacks.

One of the unique and underlying security features of the GDPR compliant datAshur PRO² is the dedicated hardware based secure microprocessor (Common Criteria EAL4+ ready), which employs built-in physical protection mechanisms designed to defend against external tamper, bypass attacks and fault injections. Unlike other solutions, the datAshur PRO² reacts to an automated attack by entering the deadlock frozen state, which renders all such attacks as useless. In plain and simple terms, without the PIN there's no way in!

Box Contents

- iStorage datAshur PRO²
- Extruded Aluminium Sleeve
- QSG - Quick Start Guide

1. LED indicators and their actions

LED	LED State	Description	LED	LED State	Description
	RED Solid 	Locked device (in either Standby or Reset states)		RED, GREEN and BLUE Blinking 	Waiting for User PIN entry
	RED - Fade Out 	Device Turning off to the Idle State		GREEN and BLUE Blinking together 	Waiting for Admin PIN entry
	GREEN Blinking 	Unlocked device as Admin (not connected to USB port)		GREEN and BLUE Blinking alternately 	Authentication in progress
	GREEN Solid 	Unlocked device as User (not connected to USB port) or device in User mode		BLUE blinking every 5 seconds 	Battery starts charging after 30 seconds when device is locked and connected to a USB port
	BLUE Solid 	Device in Admin mode			

2. Battery and LED States



Note: The normal function of the datAshur PRO² may be disturbed by strong Electro-Magnetic Interference. If so, simply power cycle the product (power off then power on) to resume normal operation. If normal operation does not resume, please use the product in a different location.

Low Battery Sensor

The datAshur PRO² incorporates voltage detection circuitry that monitors the battery output when the device is powered on. When battery output drops to 3.3V or below, the **RED** LED flashes three times and fades out. At this point, the User should connect the datAshur PRO² to a powered USB port and charge for 15-30minutes. Once recharged, the datAshur PRO² will resume normal function.

To wake from Idle State

Idle state is defined as when datAshur PRO² is not being used and all LEDs are off.

To wake datAshur PRO² from the idle state do the following.

Press and hold down the SHIFT (↑) button for one second or connect the device to a powered USB port		RED, GREEN and BLUE LEDs blink once in sequence then the GREEN LED blinks twice and finally switches to a solid RED LED indicating the device is in Standby State
--	--	---

To enter Idle State

To force datAshur PRO² to enter Idle State, execute either of the following operations:

- If the device is connected to a USB port, disconnect it.
- If the device is not connected to a USB port, press and hold down the **SHIFT** (↑) button for a second until the LED turns solid **RED** and fades out to the Idle State (off).



Note: When datAshur PRO² is unlocked and not connected to a USB port and no operations are performed within 30 seconds, the device will enter Idle State automatically. The LED turns to solid **RED** and then fades out to the idle state.

When datAshur PRO² is connected to a USB port, the **SHIFT** (↑) button does not function.

When connected to a powered USB port, a locked datAshur PRO² will start charging after 30 seconds, indicated by the **BLUE** LED blinking every 5 seconds.

Power-on States

After the device wakes from Idle State, it will enter one of the following states shown in the table below.

Power-on State	LED indication	Encryption Key	Admin PIN	Description
Standby	RED Solid	✓	✓	Waiting for Admin or User PIN entry
Reset	RED Solid	✗	✗	Waiting for configuration of an Admin PIN
Low Battery Level	RED Blinks 3 Times	✓	✓	Charge on a powered USB port for 15-30 minutes
Initial Shipment State	RED and GREEN Solid	✓	✗	Waiting for configuration of an Admin PIN

3. First Time Use

datAshur PRO² is supplied in the ‘**Initial Shipment State**’ with **no pre-set Admin PIN**. A **7-15** digit Admin PIN must be configured before the drive can be used. Once an Admin PIN has been successfully configured, it is then not possible to switch the drive back to the ‘Initial Shipment State’.

PIN Requirements:

- Must be between 7-15 digits in length
- Must not contain only repetitive numbers, e.g. (3-3-3-3-3-3-3)
- Must not contain only consecutive numbers, e.g. (1-2-3-4-5-6-7), (7-8-9-0-1-2-3-4), (7-6-5-4-3-2-1)

Password Tip: You can configure a memorable word, name, phrase or any other Alphanumerical PIN combination by simply pressing the button with the corresponding letters on it.

Examples of these types of Alphanumerical PINs are:

- For “**Password**” press the following buttons:
7 (pqrs) **2** (abc) **7** (pqrs) **7** (pqrs) **9** (wxyz) **6** (mno) **7** (pqrs) **3** (def)
- For “**iStorage**” press the following buttons:
4 (ghi) **7** (pqrs) **8** (tuv) **6** (mno) **7** (pqrs) **2** (abc) **4** (ghi) **3** (def)

Using this method, long and easy to remember PINs can be configured.

To configure an Admin PIN and unlock the datAshur PRO² for the first time, please follow the simple steps in the table below.

Instructions - First Time Use	LED	LED State
1. Press and hold down the SHIFT (↑) button for one second		RED, GREEN and BLUE LEDs blink once in sequence then the GREEN LED blinks twice and finally switches to solid RED and GREEN LEDs indicating the drive is in the Initial Shipment State
2. Press and hold down both KEY (⌘) + 1 buttons		LEDs turn to blinking GREEN and solid BLUE
3. Enter New Admin PIN and press the KEY (⌘) button once		Blinking GREEN and solid BLUE LEDs switch to a GREEN blink then back to Blinking GREEN and solid BLUE LEDs
4. Re-enter New Admin PIN and press the KEY (⌘) button again		BLUE LED rapidly blinks then switches to a solid BLUE LED and finally to a blinking GREEN LED indicating the Admin PIN has been successfully configured and drive unlocked



Note: Once datAshur PRO² has been successfully unlocked, the GREEN LED will remain blinking for 30 seconds only, during which time the datAshur PRO² needs to be connected to a powered USB port. It can be locked down immediately (if not connected to a USB port) by pressing and holding down the **SHIFT** (↑) button for a second or by clicking the 'Safely Remove Hardware/Eject' icon within your operating system when connected to a USB port.

When the datAshur PRO² is unlocked and connected to a USB port, it will not accept further instructions via the keypad.

Locking datAshur PRO²

To lock the drive, safely eject the datAshur PRO² from your host operating system and unplug from the USB port. If data is being written to the drive, unplugging the datAshur PRO² will result in incomplete data transfer and possible data corruption.

4. Unlocking datAshur PRO² with the Admin PIN

To unlock the datAshur PRO² with the Admin PIN, please follow the simple steps in the table below.

1. Press and hold down the SHIFT (↑) button for one second		RED, GREEN and BLUE LEDs blink once in sequence then the GREEN LED blinks twice and finally switches to a solid RED LED indicating the drive is in Standby State
2. In Standby State (solid RED LED) press the KEY (⌘) button once		GREEN and BLUE LEDs blink together
3. With the GREEN and BLUE LEDs blinking together, enter the Admin PIN and press the KEY (⌘) button again		GREEN and BLUE LEDs will alternately blink several times and then to a solid BLUE LED and changing to a blinking GREEN LED indicating the drive has been successfully unlocked as Admin



Note: Once datAshur PRO² has been successfully unlocked, the **GREEN** LED will remain blinking for 30 seconds only, during which time the datAshur PRO² needs to be connected to a powered USB port. It can be locked down immediately (if not connected to a USB port) by pressing and holding down the **SHIFT** (**↑**) button for a second or by clicking the 'Safely Remove Hardware/Eject' icon within your operating system when connected to a USB port.

When the datAshur PRO² is unlocked and connected to a USB port, it will not accept further instructions via the keypad.

5. To Enter Admin Mode

To Enter Admin Mode, do the following.

1. Press and hold down the SHIFT (↑) button for one second		RED , GREEN and BLUE LEDs blink once in sequence then the GREEN LED blinks twice and finally switches to a solid RED LED indicating the device is in Standby State
2. In Standby State (solid RED LED) press the KEY (Ⓝ) button once		GREEN and BLUE LEDs blink together
3. With the GREEN and BLUE LEDs blinking together, enter the Admin PIN and press the KEY (Ⓝ) button again		GREEN and BLUE LEDs will alternately blink several times and then to a solid BLUE LED changing to a blinking GREEN LED indicating the device is unlocked
4. Press the KEY (Ⓝ) button Three times within 2 seconds (KEY (Ⓝ) x 3)		Blinking GREEN LED will change to a solid BLUE LED indicating the device is in Admin mode

6. To Exit Admin Mode

When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT** (**↑**) button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

7. Changing the Admin PIN

PIN Requirements:

- Must be between 7-15 digits in length
- Must not contain only repetitive numbers, e.g. (3-3-3-3-3-3)
- Must not contain only consecutive numbers, e.g. (1-2-3-4-5-6-7), (7-8-9-0-1-2-3-4), (7-6-5-4-3-2-1)

Password Tip: You can configure a memorable word, name, phrase or any other Alphanumerical PIN combination by simply pressing the button with the corresponding letters on it.

Examples of these types of Alphanumerical PINs are:

- For **“Password”** press the following buttons:
7 (pqrs) **2** (abc) **7** (pqrs) **7** (pqrs) **9** (wxyz) **6** (mno) **7** (pqrs) **3** (def)
- For **“iStorage”** press the following buttons:
4 (ghi) **7** (pqrs) **8** (tuv) **6** (mno) **7** (pqrs) **2** (abc) **4** (ghi) **3** (def)

Using this method, long and easy to remember PINs can be configured.

To change the Admin PIN, first enter the **“Admin Mode”** as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode press and hold down both the KEY (Ⓝ) + 2 buttons		Solid BLUE LED will change to blinking GREEN and solid BLUE LEDs
2. Enter NEW Admin PIN and press KEY (Ⓝ) button		Blinking GREEN and solid BLUE LEDs will switch to a single GREEN LED blink and then back to blinking GREEN and solid BLUE LEDs
3. Re-enter the NEW Admin PIN and press KEY (Ⓝ) button		Blinking GREEN and solid BLUE LEDs change to a rapidly blinking BLUE LED and finally to a solid BLUE LED indicating the Admin PIN has been successfully changed

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

8. Setting a User PIN Policy

The Administrator can set a restriction policy for the User PIN. This policy includes setting the minimum length of the PIN (from 7 to 15 digits), as well as requiring or not the input of one or more **'Special Characters'**. The "Special Character" functions as both the **'SHIFT (↑) + digit'** buttons pressed down together.

To set a User PIN Policy (restrictions), you will need to enter 3 digits, for instance **'091'**, the first two digits (**09**) indicate the minimum PIN length (in this case, **9**) and the last digit (**1**) denotes that one or more 'Special Characters' must be used, in other words **'SHIFT (↑) + digit'**. In the same way, a User PIN Policy can be set without the need of a 'Special Character', for instance **'120'**, the first two digits (**12**) indicate the minimum PIN length (in this case, **12**) and the last digit (**0**) meaning no Special Character is required.

Once the Administrator has set the User PIN Policy, for instance '091', a new User PIN will need to be configured - see section 11, 'Adding a New User PIN in Admin Mode'. If the Administrator configures the User PIN as **'247688314'** with the use of a **'Special Character'** (**SHIFT (↑) + digit** pressed down together), this can be placed anywhere along your 7-15 digit PIN during the process of creating the User PIN as shown in the examples below.

- A. **'SHIFT (↑) + 2'**, '4', '7', '6', '8', '8', '3', '1', '4',
- B. '2', '4', **'SHIFT (↑) + 7'**, '6', '8', '8', '3', '1', '4',
- C. '2', '4', '7', '6', '8', '8', '3', '1', **'SHIFT (↑) + 4'**,



Note:

- If a 'Special Character' was used during the configuration of the User PIN, for instance, example **'B'** above, then the drive can only be unlocked by entering the PIN with the 'Special Character' entered precisely in the order configured, as per example **'B'** above - ('2', '4', **'SHIFT (↑) + 7'**, '6', '8', '8', '3', '1', '4').
- More than one 'Special Character' can be used and placed along your 7-15 digit PIN.
- Users are able to change their PIN but are forced to comply with the set 'User PIN Policy' (restrictions), if and when applicable.
- Setting a new User PIN Policy will automatically delete the User PIN if one exists.
- This policy does not apply to the 'Self-Destruct PIN'. The complexity setting for the Self-Destruct PIN and Admin PIN is always 7-15 digits, with no special character required.

To set a **User PIN Policy**, first enter the **"Admin Mode"** as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

<p>1. In Admin mode, press and hold down both KEY (Ⓟ) + 7 buttons</p>		<p>Solid BLUE LED will change to blinking GREEN and BLUE LEDs</p>
<p>2. Enter your 3 digits, remember the first two digits denote minimum PIN length and last digit (0 or 1) whether or not a special character has been used.</p>		<p>Blinking GREEN and BLUE LEDs will continue to blink</p>
<p>3. Press the SHIFT (↑) button once</p>		<p>Blinking GREEN and BLUE LEDs will change to a solid GREEN LED and finally to a solid BLUE LED indicating the User PIN Policy has been successfully set.</p>

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

9. How to delete the User PIN Policy

To delete the **User PIN Policy**, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

<p>1. In Admin mode, press and hold down both KEY (5) + 7 buttons</p>		<p>Solid BLUE LED will change to blinking GREEN and BLUE LEDs</p>
<p>2. Enter 070 and press SHIFT (↑) button once</p>		<p>Blinking GREEN and BLUE LEDs will change to a solid GREEN LED and finally to a solid BLUE LED indicating the User PIN Policy has been successfully deleted</p>

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

10. How to check the User PIN Policy

The Administrator is able to check the User PIN Policy and can identify the minimum PIN length restriction and whether or not the use of a Special Character has been set by noting the LED sequence as described below.

To check the User PIN Policy, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

<p>1. In Admin mode press and hold down both SHIFT (↑) + 7 buttons</p>		<p>Solid BLUE LED will change to blinking GREEN and BLUE LEDs</p>
<p>2. Press the KEY (Ⓟ) button and the following happens;</p> <ol style="list-style-type: none"> All LED's (RED, GREEN & BLUE) become solid for 1 second. A RED LED blink equates to ten (10) units of a PIN. Every GREEN LED blink equates to a single (1) unit of a PIN A BLUE blink indicates that a 'Special Character' was used. All LED's (RED, GREEN & BLUE) become solid for 1 second. LEDs return to solid BLUE 		

The table below describes the LED behaviour whilst checking the User PIN Policy, for instance if you have set a 12 digit User PIN with the use of a Special Character (**121**), the **RED** LED will blink once (**1**) and the **GREEN** LED will blink twice (**2**) followed by a single (**1**) **BLUE** LED blink indicating that a **Special Character** must be used.

PIN Description	3 digit Setup	RED	GREEN	BLUE
12 digit PIN with use of a Special Character	121	1 Blink	2 Blinks	1 Blink
12 digit PIN with NO Special Character used	120	1 Blink	2 Blinks	0
9 digit PIN with use of a Special Character	091	0	9 Blinks	1 Blink
9 digit PIN with NO Special Character used	090	0	9 Blinks	0

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT** (↑) button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

11. Adding a New User PIN in Admin Mode



Important: The creation of a new User PIN must comply with the ‘User PIN Policy’ if one has been configured as described in section 8, which imposes a minimum PIN length and whether a ‘Special Character’ has been used. Refer to section 10 to check the user PIN restrictions.

PIN requirements:

- Must be between 7-15 digits in length
- Must not contain only repetitive numbers, e.g. (3-3-3-3-3-3)
- Must not contain only consecutive numbers, e.g. (1-2-3-4-5-6-7), (7-8-9-0-1-2-3-4), (7-6-5-4-3-2-1)
- The **SHIFT** (↑) button can be used for additional PIN combinations - e.g. **SHIFT** (↑) + 1 is a different value than just 1. See section 8, ‘Setting a User PIN Policy’.

To add a **New User PIN**, first enter “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode press and hold down both KEY (⌘) + 3 buttons		Solid BLUE LED will change to blinking GREEN and solid BLUE LEDs
2. Enter New User PIN and press KEY (⌘) button		Blinking GREEN and solid BLUE LEDs will switch to a single GREEN LED blink and then back to blinking GREEN and solid BLUE LEDs
3. Re-enter the New User PIN and press KEY (⌘) button again		Blinking GREEN and solid BLUE LEDs change to a rapidly blinking GREEN LED and finally to a solid BLUE LED indicating a New User PIN has been successfully configured

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT** (↑) button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

12. Changing the User PIN in Admin Mode



Important: Changing the User PIN must comply with the 'User PIN Policy' if one has been configured as described in section 8, which imposes a minimum PIN length and whether a 'Special Character' has been used. Refer to section 10 to check the user PIN restrictions.

To change an existing **User PIN**, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

<p>1. In Admin mode press and hold down both KEY (Ⓝ) + 3 buttons</p>		<p>Solid BLUE LED will change to blinking GREEN and solid BLUE LEDs</p>
<p>2. Enter New User PIN and press KEY (Ⓝ) button</p>		<p>Blinking GREEN and solid BLUE LEDs will switch to a single GREEN LED blink and then back to blinking GREEN and solid BLUE LEDs</p>
<p>3. Re-enter the New User PIN and press KEY (Ⓝ) button again</p>		<p>Blinking GREEN and solid BLUE LEDs change to a rapidly blinking GREEN LED and finally to a solid BLUE LED indicating the User PIN has been successfully changed</p>

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

13. Deleting the User PIN in Admin Mode

To delete an existing **User PIN**, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

<p>1. In Admin mode press and hold down both SHIFT (↑) + 3 buttons</p>		<p>Solid BLUE LED will change to a blinking RED LED</p>
<p>2. Press and hold down both SHIFT (↑) + 3 buttons again</p>		<p>Blinking RED LED will change to a solid RED LED and then to a solid BLUE LED indicating the User PIN has been successfully deleted</p>

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT** (↑) button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

14. How to Unlock datAshur PRO² with User PIN

To unlock with the **User PIN**, the datAshur PRO² must first be in Standby State (solid **RED** LED) by pressing and holding down the **SHIFT** (↑) button for one second.

<p>1. In a standby state (solid RED LED) Press and hold down both the SHIFT (↑) + KEY (⌘) buttons</p>		<p>RED LED switches to all LEDs, RED, GREEN & BLUE blinking on and off</p>
<p>2. Enter User PIN and press the KEY (⌘) button</p>		<p>RED, GREEN and BLUE blinking LEDs will change to alternating GREEN and BLUE LEDs then to a solid GREEN LED indicating drive successfully unlocked in User Mode</p>

15. Changing the User PIN in User Mode

To change the **User PIN**, first unlock the datAshur PRO² with a User PIN as described above in section 14. Once the drive is in **User Mode** (solid **GREEN** LED) proceed with the following steps.

<p>1. In User mode press and hold down both KEY (⌘) + 4</p>		<p>Solid GREEN LED will change to a blinking GREEN LED and a solid BLUE LED</p>
<p>2. Enter New User PIN and press the KEY (⌘) button</p>		<p>Blinking GREEN and solid BLUE LEDs will switch to a single GREEN LED blink and then back to blinking GREEN and solid BLUE LEDs</p>
<p>3. Re-enter New User PIN and press the KEY (⌘) button</p>		<p>Blinking GREEN and solid BLUE LEDs will switch to a rapidly blinking GREEN LED and then to a solid GREEN LED indicating a successful User PIN change</p>



Important: Changing the User PIN must comply with the 'User PIN Policy' if one has been configured as described in section 8, which imposes a minimum PIN length and whether a 'Special Character' has been used. The administrator can refer to section 10 to check the user PIN restrictions.

16. Creating a One-Time User Recovery PIN

The User Recovery PIN is extremely useful in situations where a user has forgotten their PIN to unlock the datAshur PRO². To activate the recovery mode, the user must first enter the correct One-Time Recovery PIN, if one has been configured. The user PIN recovery process does not impact the data, encryption key and Admin PIN, however the user is forced to configure a new 7-15 digit User PIN.

To configure a One-Time 7-15 digit User Recovery PIN, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid BLUE LED) proceed with the following steps.

<p>1. In Admin mode press and hold down both KEY (Ⓟ) + 4 buttons</p>		<p>Solid BLUE LED will change to blinking GREEN and solid BLUE LEDs</p>
<p>2. Enter a One-Time Recovery PIN and press KEY (Ⓟ) button</p>		<p>Blinking GREEN and solid BLUE LEDs will switch to a single GREEN LED blink and then back to blinking GREEN and solid BLUE LEDs</p>
<p>3. Re-enter a One-Time Recovery PIN and press KEY (Ⓟ) button again</p>		<p>Blinking GREEN and solid BLUE LEDs change to a rapidly blinking GREEN LED and finally to a solid BLUE LED indicating the One-Time Recovery PIN has been successfully configured</p>

Note: When the datAshur PRO² is in Admin Mode, the BLUE LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid BLUE LED), press and hold down the **SHIFT (↑)** button for a second - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

17. Deleting the One-Time User Recovery PIN

To delete the One-Time User Recovery PIN, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid BLUE LED) proceed with the following steps.

<p>1. In Admin mode press and hold down both SHIFT (↑) + 4 buttons</p>		<p>Solid BLUE LED will change to blinking RED LED</p>
<p>2. Press and hold down both SHIFT (↑) + 4 buttons again</p>		<p>Blinking RED LED will become solid RED and then switch to a solid BLUE LED indicating that the One-Time User Recovery PIN has been successfully deleted</p>

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

18. Activating Recovery Mode and Creating New User PIN

The User Recovery PIN is extremely useful in situations where a user has forgotten their PIN to unlock the datAshur PRO². To activate the recovery mode, the user must first enter the correct One-Time Recovery PIN, if one has been configured. The user PIN recovery process does not impact the data, encryption key and Admin PIN, however the user is forced to configure a new 7-15 digit User PIN.

To activate the Recovery process and configure a new User PIN, proceed with the following steps.

1. With the drive in Idle State press and hold down the SHIFT (↑) button for one second		RED , GREEN and BLUE LEDs blink once in sequence then the GREEN LED blinks twice and finally switches to a solid RED LED indicating the drive is in Standby State
2. In Standby State press and hold down both KEY (Ⓝ) + 4 buttons		Solid RED LED will change to blinking RED and GREEN LEDs
3. Enter the One-Time Recovery PIN and press the KEY (Ⓝ) button		GREEN and BLUE LEDs alternate on and off then to a solid GREEN LED and finally to blinking GREEN and solid BLUE LEDs
4. Enter the New User PIN and press the KEY (Ⓝ) button		Blinking GREEN and solid BLUE LEDs change to a single GREEN LED blink then back to blinking GREEN and solid BLUE LEDs
5. Re-enter the New User PIN and press the KEY (Ⓝ) button again		GREEN LED blinks rapidly then becomes solid GREEN indicating the recovery process has been successful and a new user PIN configured



Important: The creation of a new User PIN must comply with the 'User PIN Policy' if one has been configured as described in section 8, which imposes a minimum PIN length and whether a special character has been used. Refer to section 10 to check the user PIN restrictions.

19. Set User Read-Only in Admin Mode

With so many viruses and Trojans infecting USB drives, the Read-Only feature is especially useful if you need to access data on the USB drive when used in a public setting. This is also an essential feature for forensic purposes, where data must be preserved in its original and unaltered state that cannot be modified or overwritten.

When the Administrator configures the datAshur PRO² and restricts User access to Read-Only, then only the Administrator can write to the drive or change the setting back to Read/Write as described in section 20. The User is restricted to Read-Only access and cannot write to the drive or change this setting in user mode.

To set the datAshur PRO² and restrict User access to Read-Only, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both “ 7 + 6 ” buttons.		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Press KEY (Ⓟ) button		GREEN and BLUE LEDs will change to a solid GREEN LED and then to a solid BLUE LED indicating the drive has been configured and restricts User access to Read-Only

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

20. Enable User Read/Write in Admin Mode

To set the datAshur PRO² back to Read/Write, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both “ 7 + 9 ” buttons.		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Press KEY (Ⓟ) button		GREEN and BLUE LEDs change to a solid GREEN LED then to a solid BLUE LED indicating the drive is configured as Read/Write

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

21. Set Global Read-Only in Admin Mode

When the Administrator configures the datAshur PRO² and restricts it to Global Read-Only, then neither the Administrator nor the User can write to the drive and both are restricted to Read-Only access. Only the Administrator is able to change the setting back to Read/Write as described in section 22.

To set the datAshur PRO² and restrict Global access to Read-Only, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both “ 5 + 6 ” buttons.		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Press KEY (b) button		GREEN and BLUE LEDs will change to a solid GREEN LED and then to a solid BLUE LED indicating the drive has been configured and restricts Global access to Read-Only

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).


To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

22. Enable Global Read/Write in Admin Mode

To set the datAshur PRO² back to Read/Write from the Global Read-Only setting, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both “ 5 + 9 ” buttons.		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Press KEY (b) button		GREEN and BLUE LEDs change to a solid GREEN LED then to a solid BLUE LED indicating the drive is configured as Read/Write







Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT** () button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.


23. How to configure a Self-Destruct PIN

You can configure a self-destruct PIN which when entered performs a Crypto-Erase on the drive (encryption key is deleted). This process deletes all configured PINs and renders all data stored on the drive as inaccessible (lost forever), the drive will then show as unlocked **GREEN** LED. Running this feature will cause the self-destruct PIN to become the new User PIN and the drive will need to be formatted before it can be reused.

To set the Self-Destruct PIN, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both KEY () + 6 buttons		Solid BLUE LED will change to blinking GREEN and solid BLUE LEDs
2. Configure a 7-15 digit Self-Destruct PIN and press the KEY () button		Blinking GREEN and solid BLUE LEDs will switch to a single GREEN LED blink and then back to blinking GREEN and solid BLUE LEDs
3. Re-enter the Self-Destruct PIN and press the KEY () button		GREEN LED will rapidly blink for several seconds and then changes to a solid BLUE LED to indicate the Self-Destruct PIN has been successfully configured

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT** () button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

24. How to Delete the Self-Destruct PIN

To delete the Self-Destruct PIN, first enter the “Admin Mode” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both SHIFT + 6 buttons		Solid BLUE LED will change to a blinking RED LED
2. Press and hold down SHIFT + 6 buttons again		Blinking RED LED will become solid and then change to a solid BLUE LED indicating the Self-Destruct PIN was successfully deleted

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

25. How to Unlock with the Self-Destruct PIN



Warning: When the Self-Destruct mechanism is activated, all data, the encryption key and the Admin/User PINs are deleted. **The Self-Destruct PIN becomes the User PIN.** No Admin PIN exists after the Self-Destruct mechanism is activated. The datAshur PRO² will need to be reset (see ‘How to perform a complete reset’ Section 35, on page 28) first in order to configure an Admin PIN with full Admin privileges including the ability to configure a User PIN.

When used, the self-destruct PIN will **delete ALL data, Admin/User PINs** and then unlock the drive. Activating this feature will cause the **Self-Destruct PIN to become the New User PIN** and the datAshur PRO² will need to be formatted before any new data can be added to the drive.

To activate the Self-Destruct mechanism, the drive needs to be in the standby state (solid **RED** LED) and then proceed with the following steps.

1. In standby state (solid RED LED), press and hold down both the SHIFT (↑) + KEY (⌘) buttons		RED LED switches to all LEDs, RED, GREEN & BLUE blinking on and off
2. Enter the Self-Destruct PIN and press the KEY (⌘) button		RED, GREEN and BLUE blinking LEDs will change to GREEN and BLUE LEDs alternating on and off for a few seconds and finally shifts to a solid GREEN LED indicating the datAshur PRO ² has successfully self-destructed

26. How to Configure an Admin PIN after a Brute Force attack or Reset

It will be necessary after a Brute Force attack or when the datAshur PRO² has been reset to configure an Admin PIN before the drive can be used.

PIN Requirements:

- Must be between 7-15 digits in length
- Must not contain only repetitive numbers, e.g. (3-3-3-3-3-3-3)
- Must not contain only consecutive numbers, e.g. (1-2-3-4-5-6-7), (7-8-9-0-1-2-3-4), (7-6-5-4-3-2-1)

If the datAshur PRO² has been brute forced or reset, the drive will be in standby state (solid RED LED). to configure an Admin PIN proceed with the following steps.

1. In Standby state (solid RED LED), press and hold down both SHIFT (↑) + 1 buttons		Solid RED LED will change to blinking GREEN and solid BLUE LEDs
2. Enter New Admin PIN and press KEY (⌂) button		Blinking GREEN and solid BLUE LEDs will switch to a single GREEN LED blink and then back to blinking GREEN and solid BLUE LEDs
3. Re-enter the New Admin PIN and press KEY (⌂) button		Blinking GREEN LED and solid BLUE LED change to BLUE LED rapidly blinking for a few seconds and then to a solid BLUE LED indicating the Admin PIN was successfully configured.

Note: When the datAshur PRO² is in Admin Mode, the BLUE LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid BLUE LED), press and hold down the **SHIFT (↑)** button for a second - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

27. Setting the Unattended Auto-Lock Clock

To protect against unauthorised access if the drive is unlocked and unattended, the datAshur PRO² can be set to automatically lock after a pre-set amount of time. In its default state, the datAshur PRO² Unattended Auto Lock time-out feature is turned off. The Unattended Auto Lock can be set to activate between 5 - 99 minutes.

To set the Unattended Auto Lock time-out, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both KEY (⌘) + 5 buttons		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Enter the amount of time that you would like to set the Auto-Lock time-out feature for, the minimum time that can be set is 5 minutes and the maximum being 99 minutes (5-99 minutes). For example enter: 05 for 5 minutes (press ‘0’ followed by a ‘5’) 20 for 20 minutes (press ‘2’ followed by a ‘0’) 99 for 99 minutes (press ‘9’ followed by another ‘9’)		
3. Press the SHIFT (↑) button		Blinking GREEN and BLUE LEDs will change to a solid GREEN for a second and then finally to a solid BLUE LED indicating the Auto-Lock time out is successfully configured

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

28. Turn off the Unattended Auto-Lock Clock

To turn off the Unattended Auto Lock, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both KEY (⌘) + 5 buttons		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Enter 00 and press the SHIFT (↑) button		Blinking GREEN and BLUE LEDs will change to a solid GREEN for a second and then finally to a solid BLUE LED indicating the Auto-Lock time out has been successfully disabled

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

29. How to check the Unattended Auto-Lock Clock

The Administrator is able to check and determine the length of time set for the unattended auto-lock clock by simply noting the LED sequence as described on the table at the bottom of this page.

To check the unattended auto-lock, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid BLUE LED) proceed with the following steps.

<p>1. In Admin mode press and hold down SHIFT (↑) + 5</p>		<p>Solid BLUE LED will change to blinking GREEN and BLUE LEDs</p>
<p>2. Press the KEY (Ⓟ) button and the following happens;</p> <ul style="list-style-type: none"> a. All LED's (RED, GREEN & BLUE) become solid for 1 second. b. Each RED LED blink equates to ten (10) minutes. c. Every GREEN LED blink equates to one (1) minute. d. All LED's (RED, GREEN & BLUE) become solid for 1 second. e. LEDs return to solid BLUE 		

The table below describes the LED behaviour whilst checking the unattended auto-lock, for instance if you have set the drive to automatically lock after **25** minutes, the RED LED will blink twice (**2**) and the GREEN LED will blink five (**5**) times.

Auto-Lock in minutes	RED	GREEN
5 minutes	0	5 Blinks
15 minutes	1 Blink	5 Blinks
25 minutes	2 Blinks	5 Blinks
40 minutes	4 Blinks	0

Note: When the datAshur PRO² is in Admin Mode, the BLUE LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid BLUE LED), press and hold down the **SHIFT (↑)** button for a second - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

30. Set Read-Only in User Mode

To set the datAshur PRO² to Read-Only, first enter the “**User Mode**” as described in section 14. Once the drive is in **User Mode** (solid GREEN LED) proceed with the following steps.

<p>1. In User mode, press and hold down both “7 + 6” buttons. (7=Read + 6=Only)</p>		<p>Solid GREEN LED will change to blinking GREEN and BLUE LEDs</p>
<p>2. Press KEY (Ⓟ) button</p>		<p>GREEN and BLUE LEDs will change to a solid GREEN LED indicating the drive is configured as Read-Only</p>

Note: 1. If a User set the drive as Read-Only, Admin can override this by setting the drive as Read/Write in Admin mode.
2. If Admin set the drive as Read-Only, the User cannot set the drive as Read/Write.

31. Enable Read/Write in User Mode

To set the datAshur PRO² to Read/Write, first enter the “**User Mode**” as described in section 14. Once the drive is in **User Mode** (solid GREEN LED) proceed with the following steps.

1. In User mode, press and hold down “ 7 + 9 ” buttons. (7=Read + 9=Write)	⇒	Solid GREEN LED will change to blinking GREEN and BLUE LEDs
2. Press KEY (b) button	⇒	GREEN and BLUE LEDs will change to a solid GREEN LED indicating the drive is configured as Read/Write

Note: 1. If a User set the drive as Read-Only, Admin can override this by setting the drive as Read/Write in Admin mode.
2. If Admin set the drive as Read-Only, the User cannot set the drive as Read/Write.

32. Brute Force Hack Defence Mechanism

The datAshur PRO² incorporates a defence mechanism to protect the drive against Brute Force attacks. By default, the initial shipment state values of the brute force limitation (consecutive incorrect PIN entries) for both the Admin PIN and User PIN is 10 and 5 for the Recovery PIN. Three independent brute force counters are used to record the incorrect attempts for each PIN authorisation (Admin, User and Recovery) as set out below.

- If a user enters an **incorrect User PIN** 10 consecutive times, the User PIN will be deleted but the data, Admin PIN and Recovery PIN remain intact and accessible.
- If an **incorrect Recovery PIN** is entered 5 consecutive times, the Recovery PIN is deleted but the data and Admin PIN remain intact and accessible.
- If an **incorrect Admin PIN** is entered 10 consecutive times, the drive will reset. All PINs and data are deleted and lost forever.

The table below assumes that all three PINs have been set up and highlights the effect of triggering the brute force defence mechanism of each individual PIN.

PIN used to unlock drive	Consecutive incorrect PIN entries	Description of what happens
User PIN	10	<ul style="list-style-type: none"> The User PIN is deleted. The Recovery PIN, the Admin PIN and all data remain intact and accessible.
Recovery PIN	5	<ul style="list-style-type: none"> The Recovery PIN is deleted. The Admin PIN and all data remain intact and accessible.
Admin PIN	10	<ul style="list-style-type: none"> The datAshur PRO² will reset. All PINs and data are deleted and lost forever.

Note: The brute force limitation is defaulted to initial shipment state values when the drive is completely reset, or self-destruct feature is activated, or brute forced. If Admin changes the User PIN, or a new User PIN is set when activating the recovery feature, the User PIN brute force counter is zeroed (0) but the brute force limitation is not affected. If Admin changes the Recovery PIN, the Recovery PIN brute force counter is zeroed.

Successful authorisation of a certain PIN will zero the brute force counter for that particular PIN, but not affect the other PINs brute force counter. Failed authorisation of a certain PIN will increase the brute force counter for that particular PIN, but not affect the other PINs brute force counter.

33. How to set the User PIN Brute Force Limitation

Note: The User PIN brute force limitation setting is defaulted to 10 consecutive incorrect PIN entries when the drive is either completely reset, brute forced or the self-destruct PIN is activated.

The brute force limitation for datAshur PRO² User PIN can be reprogrammed and set by the administrator. This feature can be set to allow attempts from 1 to 10 consecutive incorrect PIN entries.

To configure the User PIN brute force limitation, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid BLUE LED) proceed with the following steps.

<p>1. In Admin mode, press and hold down both 7 + 0 buttons</p>		<p>Solid BLUE LED will change to GREEN and BLUE LEDs blinking together</p>
<p>2. Enter the number of attempts for the brute force limitation (between 01-10), for example enter:</p> <ul style="list-style-type: none"> • 01 for 1 attempt • 10 for 10 attempts 		
<p>3. Press the SHIFT (↑) button once</p>		<p>Blinking GREEN and BLUE LEDs will switch to a solid GREEN LED for a second and then to a solid BLUE LED indicating the brute force limitation was successfully configured</p>

Note: When the datAshur PRO² is in Admin Mode, the BLUE LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid BLUE LED), press and hold down the **SHIFT (↑)** button for a second - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

34. How to check the User PIN Brute Force Limitation

The Administrator is able to observe and determine the number of consecutive times an incorrect User PIN is allowed to be entered before triggering the Brute Force defence mechanism by simply noting the LED sequence as described below.

To check the brute force limitation setting, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode press and hold down both 2 + 0 buttons		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Press the KEY (Ⓟ) button and the following happens; <ol style="list-style-type: none"> All LED's (RED, GREEN & BLUE) become solid for 1 second. Each RED LED blink equates to ten (10) units of a brute force limitation number. Every GREEN LED blink equates to one (1) single unit of a brute force limitation number. All LED's (RED, GREEN & BLUE) become solid for 1 second. LEDs return to solid BLUE 		

The table below describes the LED behaviour whilst checking the brute force limitation setting, for instance if you have set the drive to brute force after **5** consecutive incorrect PIN entries, the **GREEN** LED will blink five (**5**) times.

Brute Force Limitation Setting	RED	GREEN
2 attempts	0	2 Blinks
5 attempts	0	5 Blinks
10 attempts	1 Blink	0

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

35. How to perform a complete reset

To perform a complete reset, the datAshur PRO² must be in standby state (solid RED LED). Once the drive is reset then all Admin/User PINs, the encryption key and all data will be deleted and lost forever and the drive will need to be formatted before it can be reused. To reset the datAshur PRO² proceed with the following steps.

1. In standby state (solid RED LED) , press and hold down “0” button		Solid RED LED will change to all LEDs, RED, GREEN and BLUE blinking alternately on and off
2. Press and hold down both 2 + 7 buttons		RED, GREEN and BLUE alternating LEDs will become solid for a second and then to a solid RED LED indicating the drive has been reset



Important: After a complete reset a new Admin PIN must be configured, refer to Section 26 on page 22 on ‘How to Configure an Admin PIN after a Brute Force attack or Reset’, the datAshur PRO² will also need to be formatted before any new data can be added to the drive.

36. How to configure datAshur PRO² as Bootable



Note: When the drive is set as bootable, ejecting the drive from Operating System will not force the LED to turn RED. The drive stays solid GREEN and needs to be unplugged for next time use. The default setting of the datAshur PRO² is configured as non-bootable.

iStorage datAshur PRO² USB drives are equipped with a bootable feature to accommodate power cycling during a host boot process. When booting from the datAshur PRO², you are running your computer with the operating system that is installed on the datAshur PRO².

To set the drive as bootable, first enter the “Admin Mode” as described in section 5. Once the drive is in Admin Mode (solid BLUE LED) proceed with the following steps.

1. In Admin mode, press and hold down both KEY (Ⓟ) + 8 buttons		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Press “0” followed by a “1” (01)		GREEN and BLUE LEDs will continue to blink
3. Press the SHIFT (↑) button once		Blinking GREEN and BLUE LEDs will change to a solid GREEN LED and finally to a solid BLUE LED indicating the drive has been successfully configured as bootable

Note: When the datAshur PRO² is in Admin Mode, the BLUE LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid BLUE LED), press and hold down the SHIFT (↑) button for a second - the solid BLUE LED switches to a solid RED LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

37. How to disable the datAshur PRO² Bootable feature

To disable the datAshur PRO² Bootable Feature, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode, press and hold down both KEY (⌘) + 8 buttons		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Press “ 0 ” followed by another “ 0 ” (00)		GREEN and BLUE LEDs will continue to blink
3. Press the SHIFT (↑) button once		Blinking GREEN and BLUE LEDs will change to a solid GREEN LED and finally to a solid BLUE LED indicating the bootable feature has been successfully disabled

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).

To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT (↑)** button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

38. How to check the Bootable setting

To check the bootable setting, first enter the “**Admin Mode**” as described in section 5. Once the drive is in **Admin Mode** (solid **BLUE** LED) proceed with the following steps.

1. In Admin mode press and hold down both SHIFT (↑) + 8 buttons		Solid BLUE LED will change to blinking GREEN and BLUE LEDs
2. Press the KEY (⌘) button and one of the following two scenarios will happen;		
<ul style="list-style-type: none"> • If datAshur PRO² is configured as Bootable, the following happens; <ol style="list-style-type: none"> a. All LED's (RED, GREEN & BLUE) become solid for 1 second. b. GREEN LED blinks once. c. All LED's (RED, GREEN & BLUE) become solid for 1 second. d. LEDs return to solid BLUE • If datAshur PRO² is NOT configured as Bootable, the following happens; <ol style="list-style-type: none"> a. All LED's (RED, GREEN & BLUE) become solid for 1 second. b. All LEDs are off c. All LED's (RED, GREEN & BLUE) become solid for 1 second. d. LEDs return to solid BLUE 		

iStorage datAshur PRO² User Manual v2.3

Note: When the datAshur PRO² is in Admin Mode, the **BLUE** LED will remain on and solid for 30 seconds only, during which time the drive can accept instructions via the keypad allowing it to be configured with a host of security features. If no key event happens within 30 seconds, the datAshur PRO² will exit Admin mode automatically - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state (all LEDs off).


To immediately exit Admin Mode (solid **BLUE** LED), press and hold down the **SHIFT** (**↑**) button for a second - the solid **BLUE** LED switches to a solid **RED** LED which then fades out to the Idle state. To access the drive contents (data), the datAshur PRO² must first be in the idle state (all LEDs off) before an Admin/User PIN can be entered.

39. Formatting the datAshur PRO² for Windows


After a 'Brute Force Attack' or a complete reset the datAshur PRO² will delete all data and the encryption key. You will need to format the datAshur PRO² before it can be used.

To format your datAshur PRO², do the following:


1. Configure a new Admin PIN - see page 22, section 26, 'How to configure an Admin PIN after a Brute Force attack or reset'.
2. With the datAshur PRO² in standby state (**RED** LED), press the **KEY** (**Ⓛ**) button once and enter **New Admin PIN** to unlock (blinking **GREEN** LED).
3. Attach the datAshur PRO² to the computer.
4. Click on 'Format Disk'




5. Click 'Start'.



6. Click 'OK'.



7. Wait until the formatting process is complete. The datAshur PRO² will be recognised and it is available for use.




40. datAshur PRO² Setup for Mac OS

Your datAshur PRO² is preformatted exFAT. To reformat the drive to a Mac compatible format please read below. Once the drive is unlocked, open Disk Utility from Applications/Utilities/Disk Utilities.

To format the datAshur PRO²:

1. Select datAshur PRO² from the list of drives and volumes. Each drive in the list will display its capacity, manufacturer, and product name, such as 'iStorage datAshur PRO² Media' or 232.9 datAshur PRO².



2. Click the 'Erase' button (figure 1).




figure 1

3. Enter a name for the drive (figure 2). The default name is Untitled. The name of the drive will eventually appear on the desktop.




figure 2

4. Select a scheme and volume format to use. The Volume Format dropdown menu (figure 3) lists the available drive formats that the Mac supports. The recommended format type is 'Mac OS Extended (Journaled)'. The scheme format dropdown menu lists the available schemes to use (figure 4).




figure 3




figure 4

5. Click the 'Erase' button. Disk Utility will unmount the volume from the desktop, erase it, and then remount it on the desktop.

41. datAshur PRO² Setup for Linux (Ubuntu 18.04 LTS)


If your datAshur PRO² has been initialised and formatted in NTFS/FAT32/exFAT for Windows, you can directly use the drive on Ubuntu. If not, please read below.

To format the datAshur PRO² as EXT4 or other filesystem:

1. Open **'Show Application'** and type **'Disks'** in the search box. Click on the **'Disks'** utility when displayed.



2. Select the datAshur PRO² under 'Devices'. Click on the gears icon and choose 'Format Partition'




3. Configure a Volume Name and then select type of formatting you wish to use.

EXT4 – compatible with Linux


NTFS – Windows Only

FAT – compatible with all Operating Systems


And then press 'Next' and then 'FORMAT'



4. After the format process is finished, click  to mount the drive to Ubuntu.




5. A disk icon will be shown as seen in the image below. You can click the disk icon to open your drive.



Lock datAshur PRO² for Linux (Ubuntu 18.04 LTS)

It is **strongly recommended to right click your drive icon and then click 'Safely Remove' in the OS to eject (lock) your datAshur PRO²**, especially after data has been copied or deleted from the drive.



42. Hibernating, Suspending, or Logging off from the Operating System

Be sure to save and close all the files on your datAshur PRO² before hibernating, suspending, or logging off from the operating system.

It is recommended that you lock the datAshur PRO² manually before hibernating, suspending, or logging off from your system.

To lock, simply click the 'Safely Remove Hardware/Eject' icon within your operating system and unplug the datAshur PRO².



Attention: To ensure your data is secure, be sure to lock your datAshur PRO² if you are away from your computer.

43. How to check Firmware in Admin mode

To check the firmware revision number, first enter the "Admin Mode" as described in section 5. Once the drive is in **Admin Mode** (solid BLUE LED) proceed with the following steps.

<p>1. In Admin mode press and hold down both "3 + 8" buttons</p>		<p>Solid BLUE LED will change to blinking GREEN and BLUE LEDs</p>
<p>2. Press the KEY (⌘) button once and the following happens;</p> <ol style="list-style-type: none"> All LED's (RED, GREEN & BLUE) become solid for 1 second. RED LED blinks indicating the integral part of the firmware revision number. GREEN LED blinks indicating the fractional part. BLUE LED blinks indicating the last digit of the firmware revision number All LED's (RED, GREEN & BLUE) become solid for 1 second. RED, GREEN & BLUE LEDs switch to a solid BLUE LED 		

For example, if the firmware revision number is '2.3', the RED LED will blink twice (2) and the GREEN LED will blink three (3) times. Once the sequence has ended the RED, GREEN & BLUE LED's will blink together once and then return to Admin mode, a solid BLUE LED.

44. How to check Firmware in User Mode

To check the firmware revision number, first enter the “**User Mode**” as described in section 14. Once the drive is in **User Mode** (solid GREEN LED) proceed with the following steps.

<p>1. In User mode press and hold down both “3 + 8” buttons until GREEN and BLUE LEDs blink together</p>		<p>Solid GREEN LED will change to blinking GREEN and BLUE LEDs</p>
<p>2. Press the KEY (b) button and the following happens;</p> <ol style="list-style-type: none"> All LED's (RED, GREEN & BLUE) become solid for 1 second. RED LED blinks indicating the integral part of the firmware revision number. GREEN LED blinks indicating the fractional part. BLUE LED blinks indicating the last digit of the firmware revision number All LED's (RED, GREEN & BLUE) become solid for 1 second. RED, GREEN & BLUE LEDs switch to a solid BLUE LED 		

For example, if the firmware revision number is ‘**2.3**’, the RED LED will blink twice (**2**) and the GREEN LED will blink three (**3**) times. Once the sequence has ended the RED, GREEN & BLUE LED's will blink together once and then return to the User mode, a solid GREEN LED.

45. Technical Support

iStorage provides the following helpful resources for you:

Website:

<https://www.istorage-uk.com>

E-mail Support:

support@istorage-uk.com

Telephone Support:

+44 (0) 20 8991-6260.

iStorage Technical Support Specialists are available from 9:00 a.m. to 5:30 p.m. GMT - Monday through Friday.

46. Warranty and RMA information

ISTORAGE PRODUCT DISCLAIMER AND WARRANTY

iStorage warrants that on delivery and for a period of 36 months from delivery, its Products shall be free from material defects. However, this warranty does not apply in the circumstances described below. iStorage warrants that the Products comply with the standards listed in the relevant data sheet on our website at the time you place your order.

These warranties do not apply to any defect in the Products arising from:

- fair wear and tear;
- wilful damage, abnormal storage or working conditions, accident, negligence by you or by any third party;
- if you or a third party fail(s) to operate or use the Products in accordance with the user instructions;
- any alteration or repair by you or by a third party who is not one of our authorised repairers; or
- any specification provided by you.

Under these warranties we will, at our option, either repair, replace, or refund you for, any Products found to have material defects, provided that upon delivery:

- you inspect the Products to check whether they have any material defects; and
- you test the encryption mechanism in the Products.

We shall not be liable for any material defects or defects in the encryption mechanism of the Products ascertainable upon inspection on delivery unless you notify such defects to us within 30 days of delivery. We shall not be liable for any material defects or defects in the encryption mechanism of the Products which are not ascertainable upon inspection on delivery unless you notify such defects to us within 7 days of the time when you discover or ought to have become aware of such defects. We shall not be liable under these warranties if you make or anyone else makes any further use of the Products after discovering a defect. Upon notification of any defect, you should return the defective product to us. If you are a business, you will be responsible for the transportation costs incurred by you in sending any Products or parts of the Products to us under the warranty, and we will be responsible for any transportation costs we incur in sending you a repaired or replacement Product. If you are a consumer, please see our terms and conditions.

Products returned must be in the original packaging and in clean condition. Products returned otherwise will, at the Company's discretion, either be refused or a further additional fee charged to cover the additional costs involved. Products returned for repair under warranty must be accompanied by a copy of the original invoice, or must quote the original invoice number and date of purchase.

If you are a consumer, this warranty is in addition to your legal rights in relation to Products that are faulty or not as described. Advice about your legal rights is available from your local Citizens' Advice Bureau or Trading Standards office.

The warranties set out in this clause apply only to the original purchaser of a Product from iStorage or an iStorage authorized reseller or distributor. These warranties are non-transferable.

EXCEPT FOR THE LIMITED WARRANTY PROVIDED HEREIN, AND TO THE EXTENT PERMITTED BY LAW, ISTORAGE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ALL WARRANTIES OF MERCHANTABILITY; FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT. ISTORAGE DOES NOT WARRANT THAT THE PRODUCT WILL OPERATE ERROR-FREE. TO THE EXTENT THAT ANY IMPLIED WARRANTIES MAY NONETHELESS EXIST BY OPERATION OF LAW, ANY SUCH WARRANTIES ARE LIMITED TO THE DURATION OF THIS WARRANTY. REPAIR OR REPLACEMENT OF THIS PRODUCT, AS PROVIDED HEREIN, IS YOUR EXCLUSIVE REMEDY.

IN NO EVENT SHALL ISTORAGE BE LIABLE FOR ANY LOSS OR ANTICIPATED PROFITS, OR ANY INCIDENTAL, PUNITIVE, EXEMPLARY, SPECIAL, RELIANCE OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO, LOST REVENUES, LOST PROFITS, LOSS OF USE OF SOFTWARE, DATA LOSS, OTHER LOSS OR RECOVERY OF DATA, DAMAGE TO PROPERTY, AND THIRD-PARTY CLAIMS, ARISING OUT OF ANY THEORY OF RECOVERY, INCLUDING WARRANTY, CONTRACT, STATUTORY OR TORT, REGARDLESS OF WHETHER IT WAS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOTWITHSTANDING THE TERM OF ANY LIMITED WARRANTY OR ANY WARRANTY IMPLIED BY LAW, OR IN THE EVENT THAT ANY LIMITED WARRANTY FAILS OF ITS ESSENTIAL PURPOSE, IN NO EVENT WILL ISTORAGE'S ENTIRE LIABILITY EXCEED THE PURCHASE PRICE OF THIS PRODUCT. | 4823-2548-5683.3

iStorage[®]

© iStorage, 2019. All rights reserved.

iStorage Limited, iStorage House, 13 Alperton Lane
Perivale, Middlesex. UB6 8DH, England

Tel: +44 (0) 20 8991 6260 | Fax: +44 (0) 20 8991 6277

e-mail: info@istorage-uk.com | web: www.istorage-uk.com